


REPLACEMENT TIMER INSTALLATION INSTRUCTIONS

Timers should only be replaced by a competent electrician.

Please also note that the LIVE and NEUTRAL wires connecting the rocker switch to the timer may need to have the terminals cut off and replaced with the piggyback terminals provided at the timer end.

MI 7 Timer



- Terminal 1 : 1st End Element (Blue)
- Terminal 3 : Power Lead Neutral (Blue)
- Terminal 4 : Centre Element (Red)
- Terminal 6 : Power Lead Live (Brown)

Once repair is completed the toaster should be tested to P.A.T requirements. Dualit also recommends that a residual current device be used to protect the appliance